

Installing a Selkirk Glare Shield Step by Step by Vintage Aircraft Services of Rhome, Texas



Step 1: The existing glare shield area was stripped and refinished with non-glare matte urethane.



Step 2: The radio access plate was reinstalled.



Step 3: Randy trial fits to see where glare shield needs to be trimmed. You can install the glare shield with or without the windshield installed.



Step 4: Randy accomplishes gross trimming with shears to remove excess material.



Bill final trims on belt sander to get to trim line and produce a smooth finish.



Randy performing detail trimming for speaker and defroster holes.



Unit ready for install with all trim and penetrations accomplished.



Randy accomplishing final process by installing attaching hardware.

Photos courtesy of Vintage Aircraft Services - Aircraft Restoration and Rebuilding - Rhome, Texas - (940) 627-5938