

Selkirk Aviation Fiberglass Nosebowl Installation

Nosebowl Installation SA 40-03 and SA 40-04



1.) Remove the doubler strips. Place in spacers underneath, on half that is hooked to cowling. Then place doubler strips back onto the cowling.



2.) The above picture depicts the installation of the filter box on part number SA40-04.



3.) The above picture shows work in progress.



4.) This picture shows the clekos on the lower SA40-04 nose bowl before removing off the airplane and riveting into place.



5.) The picture above shows Mike Gossett standing next to his airplane in Coeur d'Alene, Idaho. Remove the cowling from the plane to rivet.



6.) Here is Mike's riveting partner with the finished product.

Please feel free to write or call for information on Selkirk Aviation's Fiberglass Interior Kits or other fiberglass aircraft parts. Call shop phone 208-664-9589 or email selkirkav@selkirk-aviation.com.